



TRAIL-GEAR[®]

Off Road Supply

Wheel Spacer Install Instructions

Kit Contents:

Aluminum Wheel Spacers	2.0
Lug Nuts	12.0

Remove wheel.

Apply a small amount of anti-seize or WD-40 to wheel and spacer studs.

Slide wheel spacer onto hub. Use nuts provided to attach spacer. To tighten nuts, use a thin wall 13/16" spark plug socket.

Torque nuts to 100 lbs.

Install wheel onto spacer, and use the original nuts to attach.

Torque wheel nuts to 100 lbs.

After the truck has been driven 100 miles, the wheels should be removed and the wheel spacer nuts should be re-torqued to 100 lbs.

